

CASEY TELCO

FIBER OPTIC INTERNET - FIBER OPTIC TV - FIBER OPTIC PHONE

Setting Up Your Fire TV Device:

1. Connect your Fire TV to your TV's HDMI port and plug in the power adapter.
2. Use the USB cable to connect the power adapter to your Fire TV device.
3. Put batteries in your Fire TV remote.
4. Turn on your TV and switch to the correct HDMI input.
5. If your remote doesn't pair automatically, press the Home button for about 10 seconds until you see "Press to start" on the screen.
6. Follow the on-screen instructions to connect to Wi-Fi and install updates.
7. Sign in with your Amazon account by visiting amazon.com/code on your phone or computer and entering the verification code.

Add Casey TV+ App to Your Fire TV:

1. Press the "Home" button on your remote.
2. Navigate left to the search icon (magnifying glass).
3. Type "Casey TV+" or use Voice Search to find it.
4. Select and click "Get" to download the app.
5. After installation, enter your Login and Passphrase when prompted. Contact the office if you don't have them.

Using your Fire TV Remote:

- Use the remote arrow buttons to highlight items.
- Press the center of the remote to select an item.
- Press "Home" to go back to the main screen.
- Press "Back" to return to the previous screen.



Watching Casey TV+

Access the Program Guide:

1. Highlight and expand the Casey TV+ icon on the Home Screen.
2. Press the center of the remote to open the Program Guide.
3. Use up or down buttons to select a program in blue and press "Play/Pause" to watch it.

Watch a Channel:

From the Program Guide, press and hold the center of the remote ring to enter a specific channel number.

Channel Surfing:

- While watching a program, press the top or bottom of the remote circle to change channels.
- During a program, use the Fast Forward button to advance and the Rewind button to go back

On-Screen Guide Management

Access the Program Guide:

1. Expand the Casey TV+ icon on the Home Screen.
2. Use arrows to scroll through channels.
3. Press the center to access program details, watch, record, or search.

Recording Your Programs

Making a Recording:

When selecting "Record," choose options for series or one-time recording.

Watching Your Recordings:

1. Access recorded programs from the Recordings or Search screens.
2. Highlight and press "Play/Pause" to watch a recording.

Managing Your Recordings

Current Recordings:

In the Recordings screen, scroll and press to watch or delete a program.

Future Recordings:

1. Edit start and end times for future recordings.
2. Highlight "Edit," adjust times, and save changes.

Series Rules:

- Manage automatic recordings for series programs.
- Choose recording type, maximum episodes, and times.
- Delete Series Rules without deleting Series Recordings.

Program Search

Access the Search Feature:

1. From the Program Guide, press "Back" to access the Search feature.
2. Use the typing pad or hold the Microphone button for voice search.
3. Results will display currently airing or upcoming programs.

Restart TV:

While watching live TV, open the Program Play bar and highlight "Restart" to start a program from the beginning.

Quick Guide:

- Press the lower part of the remote ring to access the recently watched channels menu.
- Highlight and press the center to watch a new channel.
- To toggle Closed Captioning, highlight the CC icon and press the center

Pause Live TV:

Press "Play/Pause" to pause and resume live TV